H61MU-E35/ H61M-E33/ H61M-E23/ H61M-P33 series

MS-7680 (v2.x) Mainboard

G52-76801XE

Copyright Notice

The material in this document is the intellectual property of **MICRO-STAR INTERNATIONAL**. We take every care in the preparation of this document, but no guarantee is given as to the correctness of its contents. Our products are under continual improvement and we reserve the right to make changes without notice.

Trademarks

All trademarks are the properties of their respective owners.

- MSI® is registered trademark of Micro-Star Int'l Co.,Ltd.
- NVIDIA® is registered trademark of NVIDIA Corporation.
- ATI® is registered trademark of ATI Technologies, Inc.
- AMD® is registered trademarks of AMD Corporation.
- Intel® is registered trademarks of Intel Corporation.
- Windows® is registered trademarks of Microsoft Corporation.
- AMI® is registered trademark of American Megatrends Inc.
- Award® is a registered trademark of Phoenix Technologies Ltd.
- Sound Blaster® is registered trademark of Creative Technology Ltd.
- Realtek® is registered trademark of Realtek Semiconductor Corporation.
- JMicron® is registered trademark of JMicron Technology Corporation.
- Netware® is a registered trademark of Novell, Inc.
- Lucid® is trademarks of LucidLogix Technologies, Ltd.

Revision History

Revision	Revision History	Date
V2.3	Add two models for PCB 2.X	January 2011

Technical Support

If a problem arises with your system and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please try the following help resources for further guidance.

- Visit the MSI website for technical guide, BIOS updates, driver updates, and other information: ***http://www.msi.com/service/download***
- Contact our technical staff at: ***http://support.msi.com***

Safety Instructions

- Always read the safety instructions carefully.
- Keep this User's Manual for future reference.
- Keep this equipment away from humidity.
- Lay this equipment on a reliable flat surface before setting it up.
- The openings on the enclosure are for air convection hence protects the equipment from overheating. DO NOT COVER THE OPENINGS.
- Make sure the voltage of the power source is at 110/220V before connecting the equipment to the power inlet.
- Place the power cord such a way that people can not step on it. Do not place anything over the power cord.
- Always Unplug the Power Cord before inserting any add-on card or module.
- All cautions and warnings on the equipment should be noted.
- Never pour any liquid into the opening that can cause damage or cause electrical shock.
- If any of the following situations arises, get the equipment checked by service personnel:
  - The power cord or plug is damaged.
  - Liquid has penetrated into the equipment.
  - The equipment has been exposed to moisture.
  - The equipment does not work well or you can not get it work according to User's Manual.
  - The equipment has been dropped and damaged.
  - The equipment has obvious sign of breakage.

  DO NOT LEAVE THIS EQUIPMENT IN AN ENVIRONMENT ABOVE 60°C (140°F), IT MAY DAMAGE THE EQUIPMENT..

CAUTION: There is a risk of explosion, if battery is incorrectly replaced.
Replace only with the same or equivalent type recommended by the manufacturer.

警告使用者:
這是甲類資訊產品，在居住的環境中使用時，可能會造成無線電干擾，在這種情況下，使用者會被要求採取某些適當的對策。

廢電池請回收
For better environmental protection, waste batteries should be collected separately for recycling special disposal.

FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice 2

Shielded interface cables and A.C. power cord, if any, must be used in order to comply with the emission limits.

VOIR LA NOTICE D'INSTALLATION AVANT DE RACCORDER AU RESEAU.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1) this device may not cause harmful interference, and
2) this device must accept any interference received, including interference that may cause undesired operation.

WEEE (Waste Electrical and Electronic Equipment) Statement

ENGLISH

To protect the global environment and as an environmentalist, MSI must remind you that...

Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2002/96/EC, which takes effect on August 13, 2005, products of "electrical and electronic equipment" cannot be discarded as municipal wastes anymore, and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life. MSI will comply with the product take back requirements at the end of life of MSI-branded products that are sold into the EU. You can return these products to local collection points.

DEUTSCH

Hinweis von MSI zur Erhaltung und Schutz unserer Umwelt

Gemäß der Richtlinie 2002/96/EG über Elektro- und Elektronik-Altgeräte dürfen Elektro- und Elektronik-Altgeräte nicht mehr als kommunale Abfälle entsorgt werden. MSI hat europaweit verschiedene Sammel- und Recyclingunternehmen beauftragt, die in die Europäische Union in Verkehr gebrachten Produkte, am Ende seines Lebenszyklus zurückzunehmen. Bitte entsorgen Sie dieses Produkt zum gegebenen Zeitpunkt ausschliesslich an einer lokalen Altgerätesammelstelle in Ihrer Nähe.

FRANÇAIS

En tant qu'écologiste et afin de protéger l'environnement, MSI tient à rappeler ceci...

Au sujet de la directive européenne (EU) relative aux déchets des équipement électriques et électroniques, directive 2002/96/EC, prenant effet le 13 août 2005, que les produits électriques et électroniques ne peuvent être déposés dans les décharges ou tout simplement mis à la poubelle. Les fabricants de ces équipements seront obligés de récupérer certains produits en fin de vie. MSI prendra en compte cette exigence relative au retour des produits en fin de vie au sein de la communauté européenne. Par conséquent vous pouvez retourner localement ces matériels dans les points de collecte.

РУССКИЙ

Компания MSI предпринимает активные действия по защите окружающей среды, поэтому напоминаем вам, что....

В соответствии с директивой Европейского Союза (ЕС) по предотвращению загрязнения окружающей среды использованным электрическим и электронным оборудованием (директива WEEE 2002/96/EC), вступающей в силу 13 августа 2005 года, изделия, относящиеся к электрическому и электронному оборудованию, не могут рассматриваться как бытовой мусор, поэтому производители вышеперечисленного электронного оборудования обязаны принимать его для переработки по окончании срока службы. MSI обязуется соблюдать требования по приему продукции, проданной под маркой MSI на территории ЕС, в переработку по окончании срока службы. Вы можете вернуть эти изделия в специализированные пункты приема.

ESPAÑOL

MSI como empresa comprometida con la protección del medio ambiente, recomienda:

Bajo la directiva 2002/96/EC de la Unión Europea en materia de desechos y/o equipos electrónicos, con fecha de rigor desde el 13 de agosto de 2005, los productos clasificados como “eléctricos y equipos electrónicos” no pueden ser depositados en los contenedores habituales de su municipio, los fabricantes de equipos electrónicos, están obligados a hacerse cargo de dichos productos al termino de su período de vida. MSI estará comprometido con los términos de recogida de sus productos vendidos en la Unión Europea al final de su periodo de vida. Usted debe depositar estos productos en el punto limpio establecido por el ayuntamiento de su localidad o entregar a una empresa autorizada para la recogida de estos residuos.

NEDERLANDS

Om het milieu te beschermen, wil MSI u eraan herinneren dat….

De richtlijn van de Europese Unie (EU) met betrekking tot Vervuiling van Electrische en Electronische producten (2002/96/EC), die op 13 Augustus 2005 in zal gaan kunnen niet meer beschouwd worden als vervuiling. Fabrikanten van dit soort producten worden verplicht om producten retour te nemen aan het eind van hun levenscyclus. MSI zal overeenkomstig de richtlijn handelen voor de producten die de merknaam MSI dragen en verkocht zijn in de EU. Deze goederen kunnen geretourneerd worden op lokale inzamelingspunten.

SRPSKI

Da bi zaštitili prirodnu sredinu, i kao preduzeće koje vodi računa o okolini i prirodnoj sredini, MSI mora da vas podesti da…

Po Direktivi Evropske unije (“EU”) o odbačenoj ekektronskoj i električnoj opremi, Direktiva 2002/96/EC, koja stupa na snagu od 13. Avgusta 2005, proizvodi koji spadaju pod “elektronsku i električnu opremu” ne mogu više biti odbačeni kao običan otpad i proizvođači ove opreme biće prinuđeni da uzmu natrag ove proizvode na kraju njihovog uobičajenog veka trajanja. MSI će poštovati zahtev o preuzimanju ovakvih proizvoda kojima je istekao vek trajanja, koji imaju MSI oznaku i koji su prodati u EU. Ove proizvode možete vratiti na lokalnim mestima za prikupljanje.

POLSKI

Aby chronić nasze środowisko naturalne oraz jako firma dbająca o ekologię, MSI przypomina, że...

Zgodnie z Dyrektywą Unii Europejskiej (“UE”) dotyczącą odpadów produktów elektrycznych i elektronicznych (Dyrektywa 2002/96/EC), która wchodzi w życie 13 sierpnia 2005, tzw. “produkty oraz wyposażenie elektryczne i elektroniczne “ nie mogą być traktowane jako śmieci komunalne, tak więc producenci tych produktów będą zobowiązani do odbierania ich w momencie gdy produkt jest wycofywany z użycia. MSI wypełni wymagania UE, przyjmując produkty (sprzedawane na terenie Unii Europejskiej) wycofywane z użycia. Produkty MSI będzie można zwracać w wyznaczonych punktach zbiorczych.

TÜRKÇE

Çevreci özelliğiyle bilinen MSI dünyada çevreyi korumak için hatırlatır:

Avrupa Birliği (AB) Kararnamesi Elektrik ve Elektronik Malzeme Atığı, 2002/96/EC Kararnamesi altında 13 Ağustos 2005 tarihinden itibaren geçerli olmak üzere, elektrikli ve elektronik malzemeler diğer atıklar gibi çöpe atılamayacak ve bu elektonik cihazların üreticileri, cihazların kullanım süreleri bittikten sonra ürünleri geri toplamakla yükümlü olacaktır. Avrupa Birliği'ne satılan MSI markalı ürünlerin kullanım süreleri bittiğinde MSI ürünlerin geri alınması isteği ile işbirliği içerisinde olacaktır. Ürünlerinizi yerel toplama noktalarına bırakabilirsiniz.

ČESKY

Záleží nám na ochraně životního prostředí - společnost MSI upozorňuje...

Podle směrnice Evropské unie ("EU") o likvidaci elektrických a elektronických výrobků 2002/96/EC platné od 13. srpna 2005 je zakázáno likvidovat "elektrické a elektronické výrobky" v běžném komunálním odpadu a výrobci elektronických výrobků, na které se tato směrnice vztahuje, budou povinni odebírat takové výrobky zpět po skončení jejich životnosti. Společnost MSI splní požadavky na odebírání výrobků značky MSI, prodávaných v zemích EU, po skončení jejich životnosti. Tyto výrobky můžete odevzdat v místních sběrnách.

MAGYAR

Annak érdekében, hogy környezetünket megvédjük, illetve környezetvédőként fellépve az MSI emlékezteti Önt, hogy ...

Az Európai Unió („EU") 2005. augusztus 13-án hatályba lépő, az elektromos és elektronikus berendezések hulladékairól szóló 2002/96/EK irányelve szerint az elektromos és elektronikus berendezések többé nem kezelhetőek lakossági hulladékként, és az ilyen elektronikus berendezések gyártói kötelessé válnak az ilyen termékek visszavételére azok hasznos élettartama végén. Az MSI betartja a termékvisszavétellel kapcsolatos követelményeket az MSI márkanév alatt az EU-n belül értékesített termékek esetében, azok élettartamának végén. Az ilyen termékeket a legközelebbi gyűjtőhelyre viheti.

ITALIANO

Per proteggere l'ambiente, MSI, da sempre amica della natura, ti ricorda che….

In base alla Direttiva dell'Unione Europea (EU) sullo Smaltimento dei Materiali Elettrici ed Elettronici, Direttiva 2002/96/EC in vigore dal 13 Agosto 2005, prodotti appartenenti alla categoria dei Materiali Elettrici ed Elettronici non possono più essere eliminati come rifiuti municipali: i produttori di detti materiali saranno obbligati a ritirare ogni prodotto alla fine del suo ciclo di vita. MSI si adeguerà a tale Direttiva ritirando tutti i prodotti marchiati MSI che sono stati venduti all'interno dell'Unione Europea alla fine del loro ciclo di vita. È possibile portare i prodotti nel più vicino punto di raccolta

CONTENTS

Copyright Notice ii
Trademarks ii
Revision History ii
Technical Support ii
Safety Instructions iii
FCC-B Radio Frequency Interference Statement iv
WEEE (Waste Electrical and Electronic Equipment) Statement v
Chapter 1 Getting Started 1-1
- Mainboard Specifications 1-2
- Mainboard Layout 1-4
- Packing Checklist 1-5

Chapter 2 Hardware Setup 2-1
- Quick Components Guide 2-2
- Screw Holes 2-3
- CPU (Central Processing Unit) 2-4
- Memory 2-8
- Power Supply 2-10
- Back Panel 2-11
- Connectors 2-13
- Jumpers 2-19
- Slots 2-20

Chapter 3 BIOS Setup 3-1
- Entering Setup 3-2
- The Menu Bar 3-4
- Main Menu 3-5
- Advanced 3-6
- Overclocking 3-11
- Mflash 3-16
- Security 3-17
- Boot 3-18
- Save & Exit 3-19

Appendix A Realtek Audio A-1
Installing the Realtek HD Audio Driver A-2
Software Configuration A-3
Hardware Default Setting A-5



Chapter 1

Getting Started

Thank you for choosing the **H61MU-E35/ H61M-E33/ H61M-E23/ H61M-P33** Series (MS-7680 v2.X) Micro-ATX mainboard. The **H61MU-E35/ H61M-E33/ H61M-E23/ H61M-P33** Series mainboards are based on **Intel® H61** chipsets for optimal system efficiency. Designed to fit the advanced **Intel® LGA1155** processor, the **H61MU-E35/ H61M-E33/ H61M-E23/ H61M-P33** Series deliver a high performance and professional desktop platform solution.

Mainboard Specifications

Processor Support

- Intel® Sandy Bridge processor in the LGA1155 package
  (For the latest information about CPU, please visit
  http://www.msi.com/service/cpu-support)

Chipset

- Intel® H61 chipset

Memory Support

- 2 DDR3 DIMMs support DDR3 1333/ 1066 DRAM (16GB Max)
- Supports Dual-Channel mode
  (For more information on compatible components, please visit
  http://www.msi.com/service/test-report)

LAN

- Supports LAN 10/100/1000 by Realtek® RTL8111E

Audio

- HD audio codec integrated by Realtek® ALC887
- Flexible 8-channel audio with jack sensing

SATA

- 4 SATA 3Gb/s ports by Intel® H61 PCH (H61MU-E35/ H61M-E33/ H61M-E23)
- 2 SATA 3Gb/s ports by Intel® H61 PCH (H61M-P33)

USB 3.0 (for H61MU-E35)

- 2 USB 3.0 rear IO ports by NEC® uPD720200F1

Connectors

- Back panel
  - 1 PS/2 keyboard/ mouse combo port
  - 2 USB 3.0 ports (for H61MU-E35)
  - 4 USB 2.0 ports
  - 1 HDMI port* (H61MU-E35/ H61M-E33/ H61M-E23)
  - 1 VGA port*
  - 1 DVI-D port*
  - 1 LAN port
  - 6 flexible audio ports (H61MU-E35/ H61M-E33) / 3 flexible audio ports (H61M-E23/ H61M-P33)

*(The HDMI, DVI-D and VGA ports only work with Integrated Graphics Processor)

- On-Board
  - 3 USB 2.0 connectors (H61MU-E35/ H61M-E33/ H61M-E23)/ 1 USB 2.0 connector (H61M-P33)
  - 1 Chassis Intrusion connector
  - 1 S/PDIF-Out connector
  - 1 Front Panel Audio connector
  - 1 TPM Module connector (H61MU-E35/ H61M-E33/ H61M-E23)
  - 1 Parallel port connector
  - 1 Serial port connector

Slots

- 1 PCIE x16 slot
- 2 PCIE x1 slots
- 1 PCI slot

Form Factor

- Micro-ATX (24.5 cm X 21.5 cm)

Mounting

- 6 mounting holes

Mainboard Layout



H61MU-E35/ H61M-E33/ H61M-E23/ H61M-P33 Series (MS-7680 v2.X) Micro-ATX Mainboard

Packing Checklist

MSI mainboard

MSI Driver/Utility DVD

SATA Cable

Back IO Shield

USB Bracket (Optional)

User's Guide

* The pictures are for reference only and may vary from the packing contents of the product you purchased.

If you need to purchase accessories and request the part numbers, you could search the product web page and find details on our web address below

http://www.msi.com/index.php



Chapter 2

Hardware Setup

This chapter provides you with the information about hardware setup procedures. While performing the installation, be careful in holding the components and following the installation procedures. For some components, if you install in the wrong orientation, the components will not work properly.

Use a grounded wrist strap before handling computer components. Static electricity may damage the components.

Quick Components Guide



Screw Holes

When you install the mainboard, you have to place the mainboard into the chassis in the correct direction. The locations of screws holes on the mainboard are shown as below.



Refer above picture to install standoffs in the appropriate locations on chassis and then screw through the mainboard screw holes into the standoffs.

Important

- *To prevent damage to the mainboard, any contact between the mainboard circuit and chassis or unnecessary standoffs mounted on the chassis is prohibited.*
- *Please make sure there are no metal components placed on the mainboard or within the chassis that may cause short circuit of the mainboard.*

CPU (Central Processing Unit)

When you are installing the CPU, make sure to install the cooler to prevent overheating. If you do not have the CPU cooler, consult your dealer before turning on the computer.

For the latest information about CPU, please visit

http://www.msi.com/service/cpu-support

Important

Overheating

Overheating will seriously damage the CPU and system. Always make sure the cooling fan can work properly to protect the CPU from overheating. Make sure that you apply an even layer of thermal paste (or thermal tape) between the CPU and the heatsink to enhance heat dissipation.

Replacing the CPU

While replacing the CPU, always turn off the ATX power supply or unplug the power supply's power cord from the grounded outlet first to ensure the safety of CPU.

Overclocking

This mainboard is designed to support overclocking. However, please make sure your components are able to tolerate such abnormal setting, while doing overclocking. Any attempt to operate beyond product specifications is not recommended. We do not guarantee the damages or risks caused by inadequate operation or beyond product specifications.

Introduction to LGA 1155 CPU

The surface of LGA 1155 CPU. Remember to apply some thermal paste on it for better heat dispersion.



CPU & Cooler Installation

When you are installing the CPU, **make sure the CPU has a cooler attached on the top to prevent overheating**. Meanwhile, do not forget to apply some thermal paste on CPU before installing the heat sink/cooler fan for better heat dispersion.

Follow the steps below to install the CPU & cooler correctly. Wrong installation will cause the damage of your CPU & mainboard.

1. Open the load level.



2. Lift the load lever up to fully open position



3. The CPU socket has a plastic cap on it to protect the contact from damage. Before you install CPU, always cover it to protect the socket pin. Romove the cap (as the arrow shows).

4. After confirming the CPU direction for correct mating, put down the CPU in the socket housing frame. Be sure to grasp on the edge of the CPU base. Note that the alignment keys are matched.

5. Visually inspect if the CPU is seated well into the socket. If not, take out the CPU with pure vertical motion and reinstall.



6. Engage the load lever while pressing down lightly onto the load plate.



7. Secure the lever near the hook end under the retention tab.

8. Make sure the four hooks are in porper position before you install the cooler.



Important

- *Confirm if your CPU cooler is firmly installed before turning on your system.*
- *Do not touch the CPU socket pins to avoid damaging.*

9. Align the holes on the mainboard with the heatsink. Push down the cooler until its four clips get wedged into the holes of the mainboard.



10. Press the four hooks down to fasten the cooler.



11. Turn over the mainboard to confirm that the clip-ends are correctly inserted.



12. Finally, attach the CPU Fan cable to the CPU fan connector on the mainboard.



Important

- *Read the CPU status in BIOS.*
- *Whenever CPU is not installed, always protect your CPU socket pin with the plastic cap covered (shown in Figure 1) to avoid damaging.*
- *Mainboard photos shown in this section are for demonstration of the CPU/ cooler installation only. The appearance of your mainboard may vary depending on the model you purchase.*
- *Please refer to the documentation in the CPU fan package for more details about the CPU fan installation.*

Memory

These DIMM slots are used for installing memory modules. For more information on compatible components, please visit http://www.msi.com/service/test-report



Dual-Channel mode Population Rule

In Dual-Channel mode, the memory modules can transmit and receive data with two data bus lines simultaneously. Enabling Dual-Channel mode can enhance the system performance. The following illustrations explain the population rules for Dual-Channel mode.



Important

- *DDR3 memory modules are not interchangeable with DDR2, and the DDR3 standard is not backwards compatible. You should always install DDR3 memory modules in the DDR3 DIMM slots.*
- *In Dual-Channel mode, make sure that you install memory modules of the* ***same type and density*** *in different channel DIMM slots.*
- *Due to the chipset resource deployment, the system density will only be detected up to 15+GB (not full 16GB) when each DIMM is installed with a 8GB memory module.*

Installing Memory Modules

1. The memory module has only one notch on the center and will only fit in the right orientation.
2. Insert the memory module vertically into the DIMM slot. Then push it in until the golden finger on the memory module is deeply inserted in the DIMM slot. The plastic clip at each side of the DIMM slot will automatically close when the memory module is properly seated.
3. Manually check if the memory module has been locked in place by the DIMM slot clips at the sides.



Important

You can barely see the golden finger if the memory module is properly inserted in the DIMM slot.

Power Supply

ATX 24-pin Power Connector: JPWR1

This connector allows you to connect an ATX 24-pin power supply. To connect the ATX 24-pin power supply, make sure the plug of the power supply is inserted in the proper orientation and the pins are aligned. Then push down the power supply firmly into the connector.

You may use the 20-pin ATX power supply as you like. If you'd like to use the 20-pin ATX power supply, please plug your power supply along with pin 1 & pin 13.



ATX 4-pin Power Connector: JPWR2

This connector is used to provide the power output to the CPU.



Important

Make sure that all the connectors are connected to proper ATX power supplies to ensure stable operation of the mainboard.

Back Panel



▸Mouse/Keyboard

The standard PS/2® mouse/keyboard DIN connector is for a PS/2® mouse/keyboard.

▸USB 2.0 Port

The USB (Universal Serial Bus) port is for attaching USB devices such as keyboard, mouse, or other USB-compatible devices.

▸USB 3.0 Port (optional)

USB 3.0 port is backward-compatible with USB 2.0 devices. Supports data transfer rate up to 5 Gbit/s (SuperSpeed).

Important

If you want to use a USB 3.0 device, you must use the USB 3.0 cable to connect to the USB 3.0 port.

▸HDMI Port (optional)

The High-Definition Multimedia Interface (HDMI) is an all-digital audio/video interface capable of transmitting uncompressed streams. HDMI supports all TV format, including standard, enhanced, or high-definition video, plus multi-channel digital audio on a single cable.

▸VGA Port

The DB15-pin female connector is provided for monitor.

▸DVI-D Port

The DVI-D (Digital Visual Interface - Digital) connector allows you to connect a LCD monitor. It provides a high-speed digital interconnection between the computer and its display device. To connect an LCD monitor, simply plug your monitor cable into the DVI -D connector, and make sure that the other end of the cable is properly connected to your monitor (refer to your monitor manual for more information.)

Important

The HDMI, VGA and DVI-D display interfaces on the mainboard are designed to serve as IGP (Integrated Graphics Processor) used. If you installed a processor without integrated graphics chip, these display ports will have no effect.

▸LAN

The standard RJ-45 LAN jack is for connection to the Local Area Network (LAN). You can connect a network cable to it.



LED	Color	LED State	Condition
Left	Yellow	Off	LAN link is not established.
		On(Steady state)	LAN link is established.
		On(brighter & pulsing)	The computer is communicating with another computer on the LAN.
Right	Green	Off	10 Mbit/sec data rate is selected.
		On	100 Mbit/sec data rate is selected.
	Orange	On	1000 Mbit/sec data rate is selected.

▸Audio Ports

These audio connectors are used for audio devices. It is easy to differentiate between audio effects according to the color of audio jacks.

- Line-In: Blue - Line In, is used for external CD player, tape-player or other audio devices.
- Line-Out: Green - Line Out, is a connector for speakers or headphones.
- Mic: Pink - Mic, is a connector for microphones.
- RS-Out (optional): Black - Rear-Surround Out in 4/ 5.1/ 7.1 channel mode.
- CS-Out (optoinal): Orange - Center/ Subwoofer Out in 5.1/ 7.1 channel mode.
- SS-Out (optional): Gray - Side-Surround Out 7.1 channel mode.

Important

If the mainboard, which equips 3 audio jacks, wants to reach the 8-channel sound effect, the 7th and 8th channels must be output from front panel.

Connectors

Serial ATA Connector: SATA1_2/ SATA5/ SATA6 (SATA1_2 is optional)

This connector is a high-speed Serial ATA interface port. Each connector can connect to one Serial ATA device.



* The MB layout in this figure is for reference only.



Important

Please do not fold the Serial ATA cable into a 90-degree angle. Otherwise, data loss may occur during transmission.

Fan Power Connectors: CPUFAN,SYSFAN1~2

The fan power connectors support system cooling fan with +12V. When connecting the wire to the connectors, always note that the red wire is the positive and should be connected to the +12V; the black wire is Ground and should be connected to GND. If the mainboard has a System Hardware Monitor chipset on-board, you must use a specially designed fan with speed sensor to take advantage of the CPU fan control.



Important

- *Please refer to the recommended CPU fans at processor's official website or consult the vendors for proper CPU cooling fan.*
- *CPUFAN support Smart fan control. You can install* **Control Center** *utility that will automatically control the CPUFAN speeds according to the actual CPUFAN temperatures.*
- *Fan cooler set with 3 or 4 pins power connector are both available for CPUFAN.*

Front Panel Connectors: JFP1, JFP2

These connectors are for electrical connection to the front panel switches and LEDs. The JFP1 is compliant with Intel® Front Panel I/O Connectivity Design Guide.



Front USB Connector: JUSB1~3 (JUSB2~3 are optional)

This connector, compliant with Intel® I/O Connectivity Design Guide, is ideal for connecting high-speed USB interface peripherals such as USB HDD, digital cameras, MP3 players, printers, modems and the like.



Important

Note that the pins of VCC and GND must be connected correctly to avoid possible damage.

Front Panel Audio Connector: JAUD1

This connector allows you to connect the front panel audio and is compliant with Intel® Front Panel I/O Connectivity Design Guide.



S/PDIF-Out Connector: JSP1

This connector is used to connect S/PDIF (Sony & Philips Digital Interconnect Format) interface for digital audio transmission.



* The MB layout in this figure is for reference only.

S/PDIF-Out Bracket (optional)

Serial Port Connector: JCOM1

This connector is a 16550A high speed communication port that sends/receives 16 bytes FIFOs. You can attach a serial device.



TPM Module connector: JTPM1 (optional)

This connector connects to a TPM (Trusted Platform Module) module (optional). Please refer to the TPM security platform manual for more details and usages.





Parallel Port Connector: JLPT1

This connector is used to connect an optional parallel port bracket. The parallel port is a standard printer port that supports Enhanced Parallel Port (EPP) and Extended Capabilities Parallel Port (ECP) mode.



Chassis Intrusion Connector: JCI1

This connector connects to the chassis intrusion switch cable. If the chassis is opened, the chassis intrusion mechanism will be activated. The system will record this status and show a warning message on the screen. To clear the warning, you must enter the BIOS utility and clear the record.



Jumpers

Clear CMOS Jumper: JBAT1

There is a CMOS RAM on board with an external battery power supply to preserve the system configuration data. With the CMOS RAM, the system can automatically boot OS every time it is turned on. If you want to clear the system configuration, please temporarily short these two pins to clear data by using a metal object.

Keep Data

Clear Data

(Use a metal object to temporarily short these two pins.)

Important

You can clear CMOS by touching two pins once with a metal object while the system is off. Avoid clearing the CMOS while the system is on; it will damage the mainboard.

Slots

PCIE (Peripheral Component Interconnect Express) Slot

The PCIE slot supports the PCIE interface expansion card.



PCIE x16 Slot



PCIE x1 Slot

PCI (Peripheral Component Interconnect) Slot

The PCI slot supports LAN card, SCSI card, USB card, and other add-on cards that comply with PCI specifications.



32-bit PCI Slot

Important

When adding or removing expansion cards, make sure that you unplug the power supply first. Read the documentation for the expansion card to configure any necessary hardware or software settings, such as jumpers, switches or BIOS configuration.

PCI Interrupt Request Routing

IRQ, or interrupt request line, are hardware lines over which devices can send interrupt signals to the microprocessor. The PCI IRQ pins are typically connected to the PCI bus pins as follows:

	Order1	Order2	Order3	Order4
PCI Slot	INT A#	INT B#	INT C#	INT D#



Chapter 3

BIOS Setup

This chapter provides information on the BIOS Setup program and allows you to configure the system for optimum use.

You may need to run the Setup program when:

- An error message appears on the screen during the system booting up, and requests you to run SETUP.
- You want to change the default settings for customized features.

Entering Setup

Power on the computer and the system will start POST (Power On Self Test) process. When the message below appears on the screen, press <DEL> key to enter Setup.

Press DEL to enter Setup Menu, F11 to enter Boot Menu

If the message disappears before you respond and you still wish to enter Setup, restart the system by turning it OFF and On or pressing the RESET button. You may also restart the system by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys.

Important

- *The items under each BIOS category described in this chapter are under continuous update for better system performance. Therefore, the description may be slightly different from the latest BIOS and should be held for reference only.*
- *Upon boot-up, the 1st line appearing after the memory count is the BIOS version. It is usually in the format:*

E7680IMS.xxx 010611 where:

1st digit refers to BIOS type as E = EFI

2nd - 5th digit refers to the model number.

6th digit refers to the chipset as I = Intel, N = nVidia, A = AMD and V = VIA.

7th - 8th digit refers to the customer as MS = all standard customers.

xxx refers to the BIOS version.

010611 refers to the date this BIOS was released.

Control Keys

<↑><↓>	Select Item
<←><→>	Select Screen
<Enter>	Select
<Esc>	Jumps to the Exit menu or returns to the main menu from a submenu
<+><->	Change Option
<F1>	General Help
<F6>	Load Optimized Defaults
<F10>	Save all the CMOS changes and exit

Getting Help

After entering the Setup menu, the first menu you will see is the Main Menu.

Main Menu

The main menu lists the setup functions you can make changes to. You can use the arrow keys (↑↓) to select the item. The on-line description of the highlighted setup function is displayed at the bottom of the screen.

Sub-Menu

If you find a right pointer symbol (as shown in the right view) appears to the left of certain fields that means a sub-menu can be launched from this field. A sub-menu contains additional options for a field parameter. You can use arrow keys (↑↓) to highlight the field and press <Enter> to call up the sub-menu. Then you can use the control keys to enter values and move from field to field within a sub-menu. If you want to return to the main menu, just press the <Esc >.

General Help <F1>

The BIOS setup program provides a General Help screen. You can call up this screen from any menu by simply pressing <F1>. The Help screen lists the appropriate keys to use and the possible selections for the highlighted item. Press <Esc> to exit the Help screen.

The Menu Bar



▸**Main Menu**

Use this menu for basic system configurations, such as time, date etc.

▸**Advanced**

Use this menu to setup the items of the BIOS special enhanced features, integrated peripherals, power management and PC health status.

▸**Overclocking**

Use this menu to specify your settings for frequency/voltage control and overclocking.

▸**Mflash**

Use this menu to read/ flash the BIOS from storage drive (FAT/ FAT32 format only).

▸**Security**

Use this menu to set supervisor and user passwords.

▸**Boot**

Use this menu to specify the priority of boot devices.

▸**Save & Exit**

This menu allows you to load the BIOS default values or factory default settings into the BIOS and exit the BIOS setup utility with or without changes.

Main Menu


Aptio Setup Utility – Copyright (C) 2010 American Megatrends, Inc.
Main Menu Advanced Overclocking Mflash Security Boot Save & Exit
System Date [Tue 01/04/2011]
System Time [00:16:08]
SATA Port1 Not Present
SATA Port2 Not Present
SATA Port3 Not Present
SATA Port4 Not Present
SATA Port5 Not Present
SATA Port6 Not Present
System Information
Intel(R) Core(TM) i3-2100 CPU @ 3.10GHz
CPUID/MicroCode 206a7/11
BIOS Version E7680IMS V11.0B2
Build Date 01/04/2011
Physical Memory 2048 MB
Cache Size 512 KB
L3 Cache Size 3072 KB
Set the Date. Use Tab to switch between Data elements.
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F6: Optimized Defaults
ESC: Exit
F10: Save & Reset
Version 2.10.1208. Copyright (C) 2010 American Megatrends, Inc.

▸System Date

This allows you to set the system to the date that you want (usually the current date). The format is <day><month> <date> <year>.

[day]	Day of the week, from Sun to Sat, determined by BIOS. Read-only.
[month]	The month from Jan. through Dec.
[date]	The date from 1 to 31 can be keyed by numeric function keys.
[year]	The year can be adjusted by users.

▸System Time

This allows you to set the system time that you want (usually the current time). The time format is <hour> <minute> <second>.

▸SATA Port1~6

Press <Enter> to enter the sub-menu. The sub-menu shows the information of installed SATA device.

Important

SATA Port1~6 are appearing when you connect the HD devices to the SATA connectors on the mainboard.

▸System Information

This area shows the CPU information, BIOS version and memory status of your system (read only).

Advanced



▸PCI Subsystem Settings

Press <Enter> to enter the sub-menu.


Aptio Setup Utility – Copyright (C) 2010 American Megatrends, Inc.
Advanced
PCI Latency Timer
[32 PCI Bus Clocks]
Value to be programmed into PCI Latency Timer Register.

▸PCI Latency Timer

This item controls how long each PCI device can hold the bus before another takes over. When set to higher values, every PCI device can conduct transactions for a longer time and thus improve the effective PCI bandwidth. For better PCI performance, you should set the item to higher values.

▸ACPI Settings

Press <Enter> to enter the sub-menu.


Aptio Setup Utility – Copyright (C) 2010 American Megatrends, Inc.
Advanced
ACPI Standby State
[S3]
Power LED
[Blinking]
Select the highest ACPI sleep state the system will enter

▸ACPI Standby State

This item specifies the power saving modes for ACPI function.

▸Power LED

This item configures how the system uses power LED on the case to indicate the sleep/suspend state.

▸ **Integrated Peripherals**

Press <Enter> to enter the sub-menu.



▸ **Onboard Lan Controller**

This item allows you to enable/ disable the onboard LAN controller.

▸ **LAN Option ROM**

This item is used to decide whether to invoke the Boot ROM of the onboard LAN.

▸ **SATA Mode**

This item is used to specify RAID/ IDE/ AHCI mode for SATA port.

▸ **HD Audio Controller**

This item allows you to enable/ disable the HD audio controller.

▸ **HPET**

The HPET (High Precision Event Timers) is a component that is part of the chipset. You can to enable it, and will provide you with the means to get to it via the various ACPI methods.

▸ **On-Chip VGA Configuration**

Press <Enter> to enter the sub-menu.


Aptio Setup Utility – Copyright (C) 2010 American Megatrends, Inc.
Advanced
On-Chip VGA Devices Configuration
Initate Graphic Adapter [PEG]
VGA Share Memory [64M]
IGD Multi-Monitor [Disabled]
Select which graphics controller to use as the primary boot device.

▸ **Initate Graphic Adapter**

This setting specifies which graphic card is the initial graphics adapter.

▸ **VGA Share Memory**

The system shares memory to the onboard graphic. This setting controls the exact memory size shared to the onboard graphic.

▸ **IGD Multi-Monitor**

When “Enabled”, the integrated graphics and extra graphics card can be configured as multi-monitor mode.

▸USB Configuration

Press <Enter> to enter the sub-menu.


Aptio Setup Utility – Copyright (C) 2010 American Megatrends, Inc.
Advanced
USB Configuration
USB Devices:
1 Drive, 1 Keyboard, 1 Mouse, 2 Hubs
USB Controller [Enabled]
Legacy USB Support [Enabled]
Onboard USB 3.0 Controller [Enabled]
USB Controller Parameters

▸USB Devices:

This item shows the type of installed USB device.

▸USB Controller

This item allows you to enable/ disable the USB controller.

▸Legacy USB Support

Select [Enabled] if you need to use a USB-interfaced device in the operating system.

▸Onboard USB 3.0 Controller

This item allows you to enable/ disable the onboard USB 3.0 controller.

▸Super IO Configuration

Press <Enter> to enter the sub-menu.


Aptio Setup Utility – Copyright (C) 2010 American Megatrends, Inc.
Advanced
Super IO Configuration
Super IO Chip F71869
Serial Port 0 Configuration
Parallel Port Configuration
Set Parameters of Serial Port 0 (COMA)

▸Serial Port 0 Configuration

Press <Enter> to enter the sub-menu.


Aptio Setup Utility – Copyright (C) 2010 American Megatrends, Inc.
Advanced
Serial Port 0 Configuration
Serial Port [Enabled]
Change Settings [Auto]
Enable or Disable Serial Port (COM)

▸Serial Port

This item allows you to enable/ disable the serial port.

▸Change Settings

Select an address and corresponding interrupt for the serial port.

▸Parallel Port Configuration

Press <Enter> to enter the sub-menu.


Aptio Setup Utility – Copyright (C) 2010 American Megatrends, Inc.
Advanced
Parallel Port Configuration
Parallel Port [Enabled]
Change Settings [Auto]
Device Mode [Printer mode.]
Select an optimal setting for Super IO device.

▸**Parallel Port**

This item allows you to enable/ disable the parallel port.

▸**Change Settings**

Select an address and corresponding interrupt for the serial port.

▸**Device Mode**

Select a device mode for parallel port.

▸**H/W Monitor**

Press <Enter> to enter the sub-menu.


Aptio Setup Utility – Copyright (C) 2010 American Megatrends, Inc.
Advanced
CPU Smart Fan Target [Disabled]
SYS Fan1 Control [100%]
SYS Fan2 Control [100%]
Pc Health Status
CPU Temperature : +231 C
System Temperature : +231 C
CPU FAN Speed : 9554 RPM
SYS FAN1 Speed 0 RPM
SYS FAN2 Speed 0 RPM
CPU Vcore Voltage : +1.176 V
CPU IO Voltage : +1.048 V
DRAM Voltage : +1.472 V
GPU Voltage : +0.448 V
3.3V : +3.312 V
5V : +5.087 V
12V : +11.968 V
Set CPU Target Temperature
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.

▸**CPU Smart Fan Target**

The Smart Fan function controls the CPU fan speed automatically depending on the current temperature to keep it with in a specific range. You can enable a fan target value here. If the current CPU fan temperature reaches to the target value, the smart fan function will be activated.

▸**SYS Fan 1 Control/ SYS Fan2 Control**

These items allow users to select how percentage of speed for the SYSFAN1/ SYSFAN2.

▸**CPU/ System Temperature, CPU FAN/ SYS FAN 1/ 2 Speed, CPU Vcore Voltage, CPU IO Voltage, DRAM Voltage, GPU Voltage, 3.3V, 5V, 12V**

These items show the current status of all of the monitored hardware devices/components such as CPU voltage, temperatures and all fans' speeds.

▸**Power Management Setup**

Press <Enter> to enter the sub-menu.


Aptio Setup Utility – Copyright (C) 2010 American Megatrends, Inc.
Advanced
EUP 2013 [Enabled]
Restore on AC Power Loss [Power off]
Restore on AC Power Loss help

▸EuP 2013

This item is designed for energy using products lot 6 2013 (EuP) aka energy related products (ErP); to reduce power consumption during system off or standby mode. Note: Enabling EuP 2013 will disable support for RTC Wake Up Event.

▸Restore on AC Power Loss

This item specifies whether your system will reboot after a power failure or interrupt occurs. Settings are:

[Power Off]	Always leaves the computer in the power off state.
[Power On]	Always leaves the computer in the power on state.
[Last State]	Restore the system to the status before power failure or interrupt occurred.

▸Wake Up Event Setup

Press <Enter> to enter the sub-menu.


Aptio Setup Utility – Copyright (C) 2010 American Megatrends, Inc.
Advanced
Setup Wake Up Configuration
Wake Up Event By [BIOS]
Resume By RTC Alarm [Disabled]
Resume By PCI or PCI-E Device [Disabled]
Resume From S3 by USB Device [Disabled]
Resume From S3 by PS/2 Mouse [Disabled]
Resume From S3 by PS/2 KB [Disabled]
Wake Up Event By

▸Wake Up Event By

Setting to [BIOS] activates the following fields, and use the following fields to set the wake up events. Setting to [OS], the wake up events will be defined by OS.

▸Resume By RTC Alarm

The field is used to enable or disable the feature of booting up the system on a scheduled time/date.

▸Date/ HH:MM:SS

If Resume By RTC Alarm is set to [Enabled], the system will automatically resume (boot up) on a specific date/hour/minute/second specified in these fields (using the <+> and <-> to select the date & time settings).

▸Resume By PCI or PCI-E Device

When set to [Enabled], the feature allows your system to be awakened from the power saving modes through any event on PCI or PCIE device.

▸Resume From S3 by USB Device

The item allows the activity of the USB device to wake up the system from S3 (Suspend to RAM) sleep state.

▸Resume From S3 by PS/2 Mouse/ KB

These items determine whether the system will be awakened from S3 state when input signal of the PS/2 mouse/ keyboard is detected.

Overclocking


Aptio Setup Utility – Copyright (C) 2010 American Megatrends, Inc.
Main Menu Advanced Overclocking Mflash Security Boot Save & Exit
Current CPU Frequency 100.00 X 32 MHz
Current DRAM Frequency 1333 MHz
Adjust CPU Ratio [31]
Adjusted CPU Frequency 3100 MHz
Adjust CPU Ratio in OS [Disabled]
Internal PLL Overvoltage [Auto]
EIST [Enabled]
OC Genie Button Operation [Disabled]
DRAM Ratio [Auto]
Adjusted DRAM Frequency 1333 MHz
DRAM Timing Mode [Auto]
Advanced DRAM Configuration
GT OverClocking [Enabled]
GT Ratio 22
Adjusted GT Frequency 1100 MHz
Spread Spectrum [Enabled]
DRAM Voltage [Auto]
CPU Features
Adjust CPU Ratio
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F6: Optimized Defaults
ESC: Exit
F10: Save & Reset
Version 2.10.1208. Copyright (C) 2010 American Megatrends, Inc.

▸**Current CPU / DRAM Frequency**

These items show the current clocks of CPU and Memory speed. Read-only.

▸**Adjust CPU Ratio**

This item controls the multiplier that is used to determine the internal clock speed of the processor relative to the external or motherboard clock speed. It is available only when the processor supports this function.

▸**Adjusted CPU Frequency**

It shows the adjusted CPU frequency. Read-only.

▸**Adjust CPU Ratio in OS**

Enable this item, it will allow you to change the CPU ratio in OS by using MSI application.

▸**Internal PLL Overvoltage**

This item are used to adjust the PLL voltage.

▸**EIST**

The Enhanced Intel SpeedStep technology allows you to set the performance level of the microprocessor whether the computer is running on battery or AC power. This field will appear after you installed the CPU which supports speedstep technology.

▸**OC Genie Button Operation**

This field is used to enable/ disable OC Genie function.

▸DRAM Ratio

This setting controls the ratio of memory frequency to enable the memory to run at different frequency combinations.

▸Adjusted DRAM Frequency

It shows the adjusted DRAM frequency. Read-only.

▸DRAM Timing Mode

Select whether DRAM timing is controlled by the SPD (Serial Presence Detect) EEPROM on the DRAM module. Setting to [Auto] enables DRAM timings and the following "Advanced DRAM Configuration" sub-menu to be determined by BIOS based on the configurations on the SPD. Selecting [Link] or [Unlink] allows users to configure the DRAM timings and the following related "Advanced DRAM Configuration" sub-menu manually.

▸Advanced DRAM Configuration

Press <Enter> to enter the sub-menu.



▸Command Rate

This setting controls the DRAM command rate.

▸tCL

This controls the CAS latency, which determines the timing delay (in clock cycles) before SDRAM starts a read command after receiving it.

▸tRCD

When DRAM is refreshed, both rows and columns are addressed separately. This setup item allows you to determine the timing of the transition from RAS (row address strobe) to CAS (column address strobe). The less the clock cycles, the faster the DRAM performance.

▸tRP

This setting controls the number of cycles for Row Address Strobe (RAS) to be allowed to precharge. If insufficient time is allowed for the RAS to accumulate its charge before DRAM refresh, refreshing may be incomplete and DRAM may fail to retain data. This item applies only when synchronous DRAM is installed in the system.

▸ tRAS

This setting determines the time RAS takes to read from and write to memory cell.

▸ tRFC

This setting determines the time RFC takes to read from and write to a memory cell.

▸ tWR

Minimum time interval between end of write data burst and the start of a precharge command. Allows sense amplifiers to restore data to cells.

▸ tWTR

Minimum time interval between the end of write data burst and the start of a column-read command. It allows I/O gating to overdrive sense amplifiers before read command starts.

▸ tRRD

Specifies the active-to-active delay of different banks.

▸ tRTP

Time interval between a read and a precharge command.

▸ tFAW

This item is used to set the tFAW (four activate window delay) timing.

▸ tWCL

This item is used to set the tWCL (Write CAS Latency) timing.

▸ tCKE

This item is used to set the tCKE timing.

▸ tRTL

This item is used to set the tRTL timing.

▸ Advanced Channel 1/ 2 Timing Configuration

Press <Enter> to enter the sub-menu. And you can set the advanced memory timing for each channel.

▸ GT OverClocking

This item allows you to enable/ disable the overclocking of integrated graphics.

▸ GT Ratio

This setting controls the ratio of integrated graphics frequency to enable the integrated graphics to run at different frequency combinations.

▸ Adjusted GT Frequency

It shows the adjusted integrated graphics frequency. Read-only.

▸ Spread Spectrum

When the mainboard's clock generator pulses, the extreme values (spikes) of the pulses create EMI (Electromagnetic Interference). The Spread Spectrum function reduces the EMI generated by modulating the pulses so that the spikes of the pulses are reduced to flatter curves.

Important

- *If you do not have any EMI problem, leave the setting at [Disabled] for optimal system stability and performance. But if you are plagued by EMI, select the value of Spread Spectrum for EMI reduction.*
- *The greater the Spread Spectrum value is, the greater the EMI is reduced, and the system will become less stable. For the most suitable Spread Spectrum value, please consult your local EMI regulation.*
- *Remember to disable Spread Spectrum if you are overclocking because even a slight jitter can introduce a temporary boost in clock speed which may just cause your over-clocked processor to lock up.*

▸DRAM Voltage

This item is used to adjust the memory voltage.

▸CPU Features

Press <Enter> to enter the sub-menu.


Aptio Setup Utility – Copyright (C) 2010 American Megatrends, Inc.
Overclocking
Hyper-threading [Enabled]
Active Processor Cores [All]
Limit CPUID Maximum [Disabled]
Execute Disable Bit [Enabled]
Intel Virtualization Tech [Disabled]
Power Technology [Custom]
C1E Support [Disabled]
OverSpeed Protection [Enabled]
Intel C-State [Enabled]
Package C State limit [No Limit]
Long duration power limit(W) 65
Long duration maintained(ms) 1000
Short duration power limit(W) 81
Primary plane turbo power limit(W) 0
Secondary plane turbo power limit(0
Enabled for Windows XP and Linux (OS optimized for Hyper-Threading Technology) and Disabled for other OS (OS not optimized for Hyper-Threading Technology). When Disabled only one thread per enabled core is enabled.
→←: Select Screen
↑↓: Select Item

▸Hyper-threading

The processor uses Hyper-Threading technology to increase transaction rates and reduces end-user response times. The technology treats the two cores inside the processor as two logical processors that can execute instructions simultaneously. In this way, the system performance is highly improved. If you disable the function, the processor will use only one core to execute the instructions. Please disable this item if your operating system doesn't support HT Function, or unreliability and instability may occur.

Important

Enabling the functionality of Hyper-Threading Technology for your computer system requires ALL of the following platform Components:

- *CPU: An Intel® Pentium® 4 Processor with HT Technology;*
- *Chipset: An Intel® Chipset that supports HT Technology;*
- *BIOS: A BIOS that supports HT Technology and has it enabled;*
- *OS: An operating system that supports HT Technology.*

For more information on Hyper-threading Technology, go to:

www.intel.com/info/hyperthreading

▸ **Active Processor Cores**

This item allows you to select the number of active processor cores.

▸ **Limit CPUID Maximum**

It is designed to limit the listed speed of the processor to older operating systems.

▸ **Execute Disable Bit**

Intel's Execute Disable Bit functionality can prevent certain classes of malicious "buffer overflow" attacks when combined with a supporting operating system. This functionality allows the processor to classify areas in memory by where application code can execute and where it cannot. When a malicious worm attempts to insert code in the buffer, the processor disables code execution, preventing damage or worm propagation.

▸ **Intel Virtualization Tech**

This item is used to enable/disable the Intel Virtualization technology. For further information please refer to Intel's official website.

▸ **Power Technology**

This item allows you to select the Intel Dynamic Power technology mode.

▸ **C1E Support**

To enable this item to read the CPU power consumption while idle. Not all processors support Enhanced Halt state (C1E).

▸ **OverSpeed Protection**

Overspeed Protection function can monitor the current CPU draws as well as its power consumption. If it exceeds a certain level, the processor automatically reduces its clock speed. If you want to overclock your CPU, set it to [Disabled].

▸ **Intel C-State**

C-state is a power management state that significantly reduces the power of the processor during idle. This field will appear after you installed the CPU which supports c-state technology.

▸ **Package C-State limit**

This field allows you to select a C-state limit.

▸ **Long duration power limit(W)**

This field allows you to adjust the TDP power limit for the long duration.

▸ **Long duration maintained(ms)**

This field allows you to adjust the maintaining time for long duration power limit.

▸ **Short duration power limit(W)**

This field allows you to adjust the TDP power limit for the short duration.

▸ **Primary/ Secondary plane turbo power limit (W)**

This field allows you to adjust the TDP limit for the primary/ secondary plane turbo.

Mflash

Aptio Setup Utility – Copyright (C) 2010 American Megatrends, Inc.
Main Menu Advanced Overclocking Mflash Security Boot Save & Exit
BIOS Boot Function [Disabled]
Select one file to Boot
Save BIOS to storage
Select one file to update BIOS
Enable this function and then we can select one BIOS file to Boot.
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F6: Optimized Defaults
ESC: Exit
F10: Save & Reset
Version 2.10.1208. Copyright (C) 2010 American Megatrends, Inc.

▸**BIOS Boot Function**

This allows you to enable/ disable the system to boot from the BIOS file inside USB drive (FAT/ 32 format only).

▸**Select one file to Boot**

When the BIOS Boot function as sets to [Enabled], this item is selectable. This item allows to select particular BIOS file from the USB/ Storage (FAT/ 32 format only) drive. And the system will boot from selected BIOS file.

▸**Save BIOS to storage**

Please setup a specific folder in specific USB/ Storage drive to save BIOS file from BIOS ROM chip data. Note: it only supports FAT/ 32 file system drive.

▸**Select one file to update BIOS**

This item allows you to select particular BIOS file from the USB/ Storage (FAT/ 32 format only) drive for updating BIOS.

Security



▸**Administrator Password**

This item is used to set the administrator password. When a administrator password has been set, you will be prompted to enter it every time you try to enter BIOS Setup.

▸**User Password**

This item is used to set the user password. When a user password has been set, you will be prompted to enter it every time you try to enter the operating system.

Important

When you select the Administrator Password / User Password item, a password box will appear on the screen. Type the password, and press <Enter>. The password typed now will replace any previously set password from CMOS memory. You will be prompted to confirm the password. Retype the password and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.

To clear a set password, just press <Enter> when you are prompted to enter the password. A message will show up confirming the password will be disabled. Once the password is disabled, the system will boot and you can enter Setup/ OS without entering any password.

These two items prevent an unauthorized person from changing any part of your system configuration.

▸**Chassis Intrusion Configuration**

Press <Enter> to enter the sub-menu.

▸**Chassis Intrusion**

This item enables or disables the feature of recording the chassis intrusion status and issuing a warning message if the chassis is once opened. To clear the warning message, set the field to [Reset]. The setting of the field will automatically return to [Enabled] later.

Boot


Aptio Setup Utility – Copyright (C) 2010 American Megatrends, Inc.
Main Menu Advanced Overclocking Mflash Security Boot Save & Exit
Boot Configuration
Full Screen Logo Display [Enabled]
Set Boot Priority
1st Boot [USB Hard Disk:Netac]
2nd Boot [Hard Disk]
3rd Boot [CD/DVD]
4th Boot [Network]
5th Boot [USB Floppy]
6th Boot [USB CD/DVD]
7th Boot [BEV]
8th Boot [UEFI:Built-in EFI ...]
USB HardDisk Drive BBS Priorities
UEFI Boot Drive BBS Priorities
Enabled or disabled Full Screen Logo Display
→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F6: Optimized Defaults
ESC: Exit
F10: Save & Reset
Version 2.10.1208. Copyright (C) 2010 American Megatrends, Inc.

▸**Full Screen Logo Display**

This item enables this system to show the company logo on the boot-up screen. Settings are:

[Enabled] Shows a still image (logo) on the full screen at boot.

[Disabled] Shows the POST messages at boot.

== Set Boot Priority ==

▸**1st~8th Boot**

You can select the boot priorities in these Boot Option items.

▸**USB HardDisk/ UEFI Boot Drive BBS Priorities**

▸**Boot Option**

You can select the USB HardDisk/ UEFI Boot priorities in these Boot Option items.

Save & Exit



▸**Discard Changes and Exit**

Use this item to abandon all changes and exit setup.

▸**Save Changes and Reset**

Use this item to save changes and reset the system.

▸**Save Changes**

Use this item to save changes.

▸**Discard Changes**

Use this item to abandon all changes.

▸**Restore Defaults**

Use this item to load the optimized default values set by the BIOS vendor.

== Boot Override ==

The installed storage devices will appear on this menu, you can select one of them be a boot device.

▸**Built-in EFI Shell**

Use this item to enter the EFI Shell.



Appendix A

Realtek Audio

The Realtek audio provides 10-channel DAC that simultaneously supports 7.1 sound playback and 2 channels of independent stereo sound output (multiple streaming) through the Front-Out-Left and Front-Out-Right channels.

Installing the Realtek HD Audio Driver

You need to install the HD audio driver for Realtek audio codec to function properly before you can get access to 2-, 4-, 6-, 8- channel or 7.1+2 channel audio operations. Follow the procedures described below to install the drivers for different operating systems.

Installation for Windows®

For Windows® XP, you must install Windows® XP Service Pack3 or later before installing the driver.

The following illustrations are based on Windows® 7 environment and could look slightly different if you install the drivers in different operating systems.

1. Insert the application DVD into the DVD-ROM drive. The setup screen will automatically appear.
2. Click Driver tab.
3. Click AUDIO button.

4. Select Realtek HD Audio Drivers to start installing the drivers.
5. Click Next to install the Realtek High Definition Audio Driver.
6. Follow the on-screen instructions to install drivers.
7. Click Finish to restart the system.

Important

The HD Audio Configuration software utility is under continuous update to enhance audio applications. Hence, the program screens shown here in this section may be slightly different from the latest software utility and shall be held for reference only.

Software Configuration

After installing the audio driver, the “Realtek HD Audio Manager” icon will appear at the notification area (lower right of the screen). You may double click the icon and the GUI will pop up accordingly.



It is also available to enable the audio driver by clicking the **Realtek HD Audio Manager** from the **Control Panel**.

Software panel overview

The following figure describes the function of the Realtek HD Audio Manager panel.



■ Device Selection

Here you can select a audio output source to change the related options. The “check” sign (in orange) indicates the devices as default.

■ Volume Adjustment

You can control the volume or balance the right/left side of the speakers that you plugged in front or rear panel by adjust the bar.

■ Application Enhancement

The array of options will provide you a complete guidance of anticipated sound effect for both output and input device.

■ Jack status panel

This panel depicts all render and capture devices currently connected with your computer.

Auto popup dialog

When you plug into the device at the jack, a dialogue window will pop up asking you which device is current connected.



As you know, each jack corresponds to its default setting, you can refer to the next section “Hardware Default Setting”.

Hardware Default Setting

The following diagrams are audio back panel default setting.

- **Backpanel audio jacks to 2-channel speakers diagram**



- **Backpanel audio jacks to 4-channel speakers diagram**



- Backpanel audio jacks to 6-channel speakers diagram



- Backpanel audio jacks to 8-channel speakers diagram